みんなの想いを OmoiO Instruction and Installation manuals

Fitting board

FIT

For both wall and floor fixing

For safety, please be sure read this book carefully in detail. You are responsible for the safe operation of this product.

IMPORTANT

- This product must be properly installed according to the manufacture's instructions.
- Please note that we will NOT be liable in the event an accident occurs due to improper use.
- Retain for future reference.

AWARNING: DO NOT stand on the fitting board until the board is opened completely and placed on the floor.

WARNING : DO NOT jump or make strenuous movement on the fitting board.

WARNING : DO NOT use broken or damaged products.

WARNING : DO NOT use for any purpose other than changing clothes.

▲WARNING : DO NOT modify the product.

WARNING : Carry out daily inspections to use the product safely.

▲WARNING : Flammable-Keep Fire Away

PRODUCT

This product is changing board installed in restroom of facilities etc.



Copyright © MIZUKAMI CO., Ltd All Rights Reserved. MADE IN JAPAN

Instruction manual

SPECIFICATION

- · Can change clothes hygienically by removing footwear.
- Compact design with a thickness of 64 mm when stored.
- · Labelled usege instructions and safety masseges in four languages.
- Product have mounting hardware included.
- Product manufactured in JAPAN.

PRODUCT SIZE



MAINTENANCE

Cleaning method

Normal cleaning method

- ① Soak a soft cloth with clean water or lukewarm water, and then wring out thoroughly before wiping.
- ② Wipe away any moisture thoroughly with a dry cloth.
- Cleaning method for when the product is very dirty
 - ① Wipe with a cloth soaked lightly with a mild detergent.
 - ② Soak a soft cloth with clean water or lukewarm water, and then wring out thoroughly before wiping away any detergent.
 - ③ Wipe away any moisture thoroughly with a dry cloth.

Caution : DO NOT use the following items that may damage the surface of the product.

- · Cleanser, detergent containing particles such as polishing powders.
- Acidic detergent, alkaline detergent, chlorine bleach.
- Nylon scrubbing brush, brush, etc.
- · Solvents such as thinner and benzine.

INSPECTION CRITERIA

- There shall be no damage to the product.
- $\cdot\,$ Opening and closing operations shall be smooth with no rattling.
- There shall be no looseness or removal of screws.
- The labels shall not be torn or faded, and the contents readable.

If there are any abnormalities

1

Discontinue use immediately and contact your dealer.

SAFETY NOTES

- \cdot For safety, make sure to read this Installation Manual carefully and install the product correctly.
- \cdot We recommend that a professional installer set up the fitting board so that it is set up securely.
- \cdot Be sure to install the fitting board on the wall surface.
- \cdot We are NOT liable for any accidents and/or damage that may occur if the Fitting board is NOT set up correctly.
- \cdot Correctly fix the SMARTPLUG securely to the concrete layer.

TOOLS NEEDED



Step 0-Packing confirmation

- \checkmark Remove products from the shipping container and check for any freight damage.
- \checkmark Please check if you have all the hardware.

Installation manual

Installing method for Fitting board FIT

Step 1-Insert the SMARTPLUG into the wall surface

Installing method for SMARTPLUG

 \cdot Make marks on the wall surface (3places) for insertingthe SMARTPLUG.



If the wall and floor foundations are wood or LGS, DO NOT use SMARTPLUG.

Step 2-Mount the body

Place the body against the bracket to which it is to be installed, and then fix securely with countersunk screws.



Step 3-Installation complete

• Install the product, and then attach pictures, signs, and label to places that are easily visible such as the restroom or entrance of the facility.

• Give this book to the manager of the facility.

